

## Anleitung für die Verarbeitung von CW 2000

### Als Ausgleichsschüttung:

#### 1. Vorbereitung

- Höhenunterschied feststellen
- Rieselschutz bzw. Randdämmstreifen bei Bedarf anbringen
- Überdeckung v. Rohren und Kanälen: mind. 10mm

#### 2. Verarbeitung

- Schüttung mit Hilfe von Nivellierleisten o. Nivelliergerät um 5mm überhöht einbringen
- Schüttung entsprechend der Höhe der Nivellierleisten o. mit Nivelliergerät abziehen
- Schüttung ist sofort begehrbar – Estrichsysteme können verlegt werden
- bei Verarbeitung mit Nivelliergerät Verarbeitungshinweise beachten

Verbindlichkeiten können aus dieser Information nicht abgeleitet werden

---

## Installation Overview of CW 2000

### As levelling fill:

#### 1. Preparation

- Determine the level difference
- Lay out the levelling according to floor levelling battens
- Cover pipes, canals and feeding lines with a minimum of 10mm

#### 2. Installation

- Install floor levelling battens at required height plus 5 mm
- Filling can be walked on immediately
- Set the height of the material and plane it with levelling rod
- When using the levelling device Cembot refer to user manual for further instructions

Liabilities not derivable

---